

SAFETY RECALL

Safety Recall Notification for RECARO Signo Car Seats Manufactured from February 1st, 2008 through September 30th, 2008.



RECARO SIGNO - midnight desert

Mfr: 330.01.MM14
UPC #: 882845600013
R US Item #: 86718

RECARO SIGNO - cobalt

Mfr: 330.01.MM58
UPC #: 882845700037
R US Item #: 86726

RECARO SIGNO - blush

Mfr: 330.01.MM5A
UPC #: 882845700020
R US Item #: 86739

What Is This Recall About

A potential defect of the harness system was discovered. The harness adjuster strap on some seats may slip within the metal adjuster (A-lock) that controls tightness of the harness and may prevent the harness from being properly tightened. If this condition existed and a vehicle crash occurred, the child would not be securely fastened to their child restraint system and may sustain an injury.

RECARO is requesting consumers to inspect their Signo seat restraint systems to confirm proper function of the harness adjuster

To check your restraint:

- (1) On your empty car seat, fully tighten the harness system by pulling on the harness adjuster strap,
 - (2) Pull on both shoulder harnesses without lifting or pressing the harness adjuster release lever (located on the front of the restraint under the cover flap).
- If the harness straps loosen, use of the restraint should be stopped! Contact RECARO at the number below for a replacement.
 - If the harness straps remain tight, the restraint can continue to be used, and no further action is necessary.

Please contact our customer service department at 1-888-473-2290 or E-mail at safety@recarousa.com with any questions or concerns regarding this issue. When you call, please have the model, serial number and manufacturer date on hand.

RECARO North America, Inc.

4120 Luella Lane, Auburn Hills, MI 48326, USA

Phone: 248-364-3818 Fax: 248-364-3804

800-line: 1-888-473-2290